

Maintenance (C markets*) Boxster / S (981), Cayman / S (981) as of 2014 model

	Work instruction for			
Vehicle Ident. No	order no.			
☐ Maintenance at 60,000, 120,000, 180,000, 240,000 km/36,00	00, 72,000, 108,000, 144,000	miles etc.		
(Labour operation 03 16 00) For descriptions of the individual maintenance tasks				
Information: If the mileage for a regular service is not rea	ached, maintenance must be car	ried out after 4, 8, 12 years.		
The term "checking" includes all necessary subsequent not include repairing, replacing and reconditioning parts		ting, correcting and topping up, but does	✓	
Electrics				
Windscreen wiper/washer system, headlight cleaning sy	stem: check function			
Horn: check function				
Tyres: check tyre pressure (TPM)				
Diagnostic system: read out fault memory; reset mainter	nance interval			
Inside the vehicle				
Particle filter: replace filter element				
Seat belts: check function and condition				
Door locks: check function				
Front luggage compartment				
Check front lid lock and safety hook of the front lid to en-	sure that they are secure and fur	nction properly		
Replace air intake pre-filter				
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use				
windscreen cleaners approved by Porsche				
Outside the vehicle				
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89)**				
Check wiper blades				
All headlights: check adjustment				
Radiators and air intakes: visual inspection for exterior soiling and blockage				
Brake system: visual inspection of brake pads and brake discs for wear				
Brake hoses: visual inspection for damage				
Under the vehicle				
Drain engine oil				
Change oil filter				
Underbody panels: visual inspection for completeness, s	secure installation and damage			
Tyres: check condition				
Visual inspection for leaks (oils and other fluids)				
Brake lines: visual inspection for damage, routing and co	orrosion			
Steering gear: visual inspection of the bellows for damage	ge			
Tie rod joints: check the play and dust bellows				
Drive shafts: visual inspection of the boots for leaks and damage				
Axle joints: check the play and visually inspect the dust boots for damage				
Exhaust system: visual inspection for leaks and damage				
Rear luggage compartment				
Air cleaner: replace filter elements				
Fill in engine oil				
Coolant: check level and antifreeze				
Engine compartment				
Throttle housing: clean inside**				
Fuel lines and connections: visual inspection				
Visual inspection for leaks (oils and other fluids)				

^{*} For country allocation, see overview of A, B and C markets

^{**} Applies only for China



Maintenance (C markets*) Boxster / S (981), Cayman / S (981) as of 2014 model

Vehicle Ident. No	Work instruction for order no.			
Additional maintenance for another place				
☐ Additional maintenance for spark plugs (Labour operation 03 81 00)		[√		
Replace spark plugs	every 30,000 km/18,000 mls or every 4 years			
	5.6.1, 5.3,600 mm 1.5,600 mm 5. 6.6.1, 1.30m 5			
☐ Additional maintenance for drive belt (Labour operation 03 60 00)				
Check drive belt	at 60,000 km/36,000 mls or every 4 years			
Check drive belt	at 150,000 km/90,000 mls or every 10 years			
Check drive belt	at 240,000 km/144,000 mls or every 16 years			
☐ Additional maintenance every 90,000 km/54,00	00 mls or every 6 years	•		
(Labour operation 03 83 00)	of this of every o years			
Replace drive belt				
☐ Additional maintenance every 120,000 km/72,0	000 mls or every 4 years	•		
(Labour operation 03 85 00)	out this of every 4 years			
Ancillary unit mounts and chassis: visual inspection of all re	rubber mountings and boots for damage			
☐ Additional maintenance every 180,000 km/108,		•		
(Labour operation 03 88 00)	,000 mis or every 12 years			
Manual transmission: change oil				
PDK transmission: change transmission oil				
PDK transmission: change clutch fluid				
☐ Every 2 years				
(Labour operation 03 51 00)				
Change brake fluid (use only original Porsche brake fluid)				
Prepare condition report for long-life guarantee				
Tyre sealing compound: Check use-by date and replace if	necessary			
	•	•		
Signature (mechanic):	_			
Test drive:				
	ot brake (also actuation travel), engine, clutch, steering, transmissi			
conditioning and instruments: check function	ort switch, sports exhaust system, door mirror fold-in function, heat	ing, air		
Oils, fluids: visual inspection for leaks				
2 3, 3 1 1 2 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1				
	<u></u>			
Signature (final check):		\neg		
	Porsche Centre			