

Maintenance (China*) Macan as of 2014 model

Vehicle Ident. No.		for order no.	
	-		

□ Maintananaa	
Maintenance	
at 60000, 120000, 180000, 240000 km / 36000, 72000, 108000, 144000 miles etc. (Labour operation: 03 16 00)	
For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual	
Note: If the mileage for a regular service is not reached, maintenance must be carried out after 4, 8, 12 years.	
The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and	
topping up, but does not include repairing, replacing and reconditioning parts or assemblies.	- ✓
	_
Electrics	_
Windscreen wiper/washer system, headlight cleaning system: check function	\bot
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory and transfer gear wear integrator; reset maintenance interval; read	
out soot mass in particle filter (Macan S Diesel only)	_
Inside the vehicle	
Seat belts: check function and condition	
Particle filter: replace filter element	
Outside the vehicle	
Check wiper blades	
All headlights: check adjustment	
Trailer hitch: check function	
Tyres and spare wheel: check condition	
Brake system: check brake pads and brake discs for wear	
Brake hoses: visual inspection for damage	
Radiators and air intakes: visual inspection for external contamination and blockage	
Check and add reducing agent AdBlue® (Macan S Diesel only)	
Mix fuel in fuel tank with additive [Keropur from Porsche, Part No. 000 043 206 89 (China only)]	
Under the vehicle	
Underbody panels: visual inspection for completeness, secure installation and damage	
Drain engine oil, change oil filter (observe oil change service plan for the Macan/S Diesel)	
Visual inspection for leaks from underneath (oils and other fluids)	
Brake lines: visual inspection for damage, routing and corrosion	
Steering gear: visual inspection of the bellows for damage	
Tie rod joints: check play and dust bellows	
Drive shafts: visual inspection of the boots for leaks and damage	
Cardan shaft: visual inspection of the rubber bellows for damage	
Axle joints: check the play and visually inspect the dust boots for damage	
Exhaust system: visual inspection for leaks and damage, check engine mount	
Replace fuel filter (Macan S Diesel only)	
Engine compartment	
Fill in engine oil	
Check drive belt (only if vehicle is used for off-road driving)	
Fuel lines and connections: visual inspection	
Visual inspection for leaks from above (oils and other fluids)	

Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of

year, only use windscreen cleaners approved by Porsche

Coolant: check level and antifreeze

Throttle housing: clean inside (China only)

^{*} For country allocation, see overview of A, B and C markets



Maintenance (China*) Macan as of 2014 model

Vehicle Ident. No. Work instruction for order no.	
□ Additional maintenance every 2 years (Labour operation: 03 51 00)	
Change brake fluid (use only original Porsche brake fluid)	
Prepare condition report for long-life guarantee	
Tyre sealing compound: check use-by date and replace if necessary	
□ Additional maintenance every 4 years (Labour operation: 03 52 00)	
Replace reducing agent AdBlue® (Macan S Diesel) (on vehicles with a mileage of less than 15,000 km/10,000 miles in four years)	
□ Additional maintenance for spark plugs every 20000 km / 12000 mls or every 2 years (Labour operation: 03 81 00)	
Replace spark plugs	
□ Additional maintenance every 90000 km / 54000 mls or every 4 years (Labour operation: 03 83 00)	
Air cleaner: replace filter element (Macan S Diesel)	
□ Additional maintenance every 120000 km / 72000 mls or every 4 years (Labour operation: 03 85 00)	
Air cleaner: replace filter elements (Macan/S/Turbo)	
□ Additional maintenance every 240000km / 144000mls or every 16 years (Labour operation: 03 95 00)	
All-wheel final drive: change oil	
Rear final drive: change oil	
☐ Additional maintenance every 60000km / 36000mls or every 4 years (Labour operation: 03 79 00)	
PDK transmission: change oil and filter	
Signature (mechanic):	
Test drive:	
Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering, transmission, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instrument check function	ıts:
Oils, fluids: visual inspection for leaks	
Signature (final check):	
Porsche Centre	