

Intermediate maintenance (C markets*) Boxster (981), Boxster S (981) as of 2013 model

	Work instruction for	-
Vehicle Ident. No.	order no.	

□ Intermediate maintenance

at 30,000, 90,000, 150,000, 210,000 km/18,000, 54,000, 90,000, 126,000 miles etc.
(Labour operation 03 14 00)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual

Information: If the mileage for a regular service is not reached, maintenance must be carried out after 2, 6, 10..... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

Electrics
Windscreen wiper/washer system, headlight cleaning system: check function
Horn: check function
Tyres: check tyre pressure (TPM)
Diagnostic system: read out fault memory; reset maintenance interval
Inside the vehicle
Particle filter: replace filter element
Front luggage compartment
Check front lid lock and safety hook of the front lid to ensure that they are secure and function properly
Replace air intake pre-filter
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of year, only use
windscreen cleaners approved by Porsche
Outside the vehicle
Mix fuel in fuel tank with additive (Keropur from Porsche; Part No. 000 043 206 89)**
Check wiper blades
All headlights: check adjustment
Radiators and air intakes: visual inspection for exterior soiling and blockage
Under the vehicle
Drain engine oil
Change oil filter
Tyres: check condition
Brake lines: visual inspection for damage, routing and corrosion
Brake hoses: visual inspection for damage
Brake system: visual inspection of brake pads and brake discs for wear (without removing and fitting wheels)
Drive shafts: visual inspection of the boots for leaks and damage
Rear luggage compartment
Fill in engine oil
Coolant: check level and antifreeze

* For country allocation, see overview of A, B and C markets

** Applies only for China



Intermediate maintenance (C markets*) Boxster (981), Boxster S (981) as of 2013 model

Vehicle Ident. No	Work instruction for order no.	
Additional maintenance for spark plugs		
(Labour operation 03 81 00)	00.000	✓
Replace spark plugs	every 30,000 km/18,000 mls or every 4 years	
Additional maintenance for drive belt		
(Labour operation 03 60 00)		
Check drive belt	at 60,000 km/36,000 mls or every 4 years	
Check drive belt	at 150,000 km/90,000 mls or every 10 years	
Check drive belt	at 240,000 km/144,000 mls or every 16 years	
□ Additional maintenance every 90,000 km/54,00 (Labour operation 03 83 00)	00 mls or every 6 years	
Replace drive belt		
 Additional maintenance every 120,000 km/72,0 (Labour operation 03 85 00) 		
Ancillary unit mounts and chassis: visual inspection of all	rubber mountings and boots for damage	
 Additional maintenance every 180,000 km/108 (Labour operation 03 88 00) Manual transmission: change oil 	8,000 mls or every 12 years	
PDK transmission: change transmission oil		
PDK transmission: change clutch fluid		
Every 2 years (Labour operation 03 51 00)		
Change brake fluid (use only original Porsche brake fluid)		
Prepare condition report for long-life guarantee]	
Every 4 years		
(Labour operation 03 52 00)		
Replace tyre sealant		
Signature (mechanic):	_	
Test drive:		
	oot brake (also actuation travel), engine, clutch, steering, transmission, oort switch, sports exhaust system, door mirror fold-in function, heating, a	ir
Oils, fluids: visual inspection for leaks		
		I
Signature (final check):		Γ

Porsche Centre