

Intermediate maintenance (China*) Macan as of 2014 model

Vehicle Ident. No. Work instruction for order no.	
□ Intermediate maintenance at 30000, 90000, 150000, 210000 km / 18000, 54000, 90000, 126000 miles etc. (Labour operation: 03 14 00) For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual Note: If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10 years.	
The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.	✓
Electrics	_
Windscreen wiper/washer system, headlight cleaning system: check function	
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory and transfer gear wear integrator; reset maintenance interval; read out soot mass in particle filter (Macan S Diesel only)	
Inside the vehicle	
Particle filter: replace filter element	
Outside the vehicle	
Check wiper blades	
All headlights: check adjustment	
Mix fuel in fuel tank with additive [Keropur from Porsche, Part No. 000 043 206 89 (China only)]	
Check and add reducing agent AdBlue® (Macan S Diesel only)	
Under the vehicle	
Drain engine oil, change oil filter (observe oil change service plan for the Macan/S Diesel)	
Tyres and spare wheel: check condition	
Brake lines: visual inspection for damage, routing and corrosion	
Brake hoses: visual inspection for damage	_
Brake system: check brake pads and brake discs for wear (without removing wheels)	
Drive shafts: visual inspection of the boots for leaks and damage	$-\!\!\!\!\!+$
Cardan shaft: visual inspection of the rubber bellows for damage	+
Radiators and air intakes: visual inspection for external contamination and blockage	_
Engine compartment	-
Fill in engine oil	+
Coolant: check level and antifreeze Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of	+
year, only use windscreen cleaners approved by Porsche	
Throttle housing: clean inside (China only)	

^{*} For country allocation, see overview of A, B and C markets



Intermediate maintenance (China*) Macan as of 2014 model

Vehicle Ident. No Work instruction for order no.	
□ Additional maintenance every 2 years (Labour operation: 03 51 00)	
Change brake fluid (use only original Porsche brake fluid)	
Prepare condition report for long-life guarantee	
Tyre sealing compound: check use-by date and replace if necessary	
□ Additional maintenance every 4 years (Labour operation: 03 52 00)	
Replace reducing agent AdBlue® (Macan S Diesel) (on vehicles with a mileage of less than 15,000 km/10,000 miles in four years)	
□ Additional maintenance for spark plugs	
every 20000 km / 12000 mls or every 2 years	
(Labour operation: 03 81 00)	
Replace spark plugs	1
□ Additional maintenance every 90000 km / 54000 mls or every 4 years	
(Labour operation: 03 83 00)	
Air cleaner: replace filter element (Macan S Diesel)	
□ Additional maintenance every 120000 km / 72000 mls or every 4 years (Labour operation: 03 85 00)	
Air cleaner: replace filter elements (Macan/S/Turbo)	T
□ Additional maintenance every 240000km / 144000mls or every 16 years (Labour operation: 03 95 00)	-
All-wheel final drive: change oil	\top
Rear final drive: change oil	\top
☐ Additional maintenance every 60000km / 36000mls or every 4 years (Labour operation: 03 79 00)	
PDK transmission: change oil and filter	T
Signature (mechanic): Test drive:	
Remote control, front seats, electric parking and foot brakes (also actuation travel), engine, clutch, steering,	$\overline{}$
transmission, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments: check function	
Oils, fluids: visual inspection for leaks	
Signature (final check):	\neg
Porsche Centre	1