PORSCHE

Intermediate maintenance (B markets*)

Macan

as of 2014 model

Vehicle Ident. No.

Work instruction for order no.

□ Intermediate maintenance

at 30000, 90000, 150000, 210000 km/20000, 60000, 100000, 140000 mls etc. (Labour operation: 03 14 00..)

For descriptions of the individual maintenance tasks, see PIWIS Information System Workshop Manual **Note:** If the mileage for a regular service is not reached, intermediate maintenance must be carried out after 2, 6, 10... years.

The term "checking" includes all necessary subsequent work, such as adjusting, readjusting, correcting and topping up, but does not include repairing, replacing and reconditioning parts or assemblies.

Electrics	
Windscreen wiper/washer system, headlight cleaning system: check function	
Horn: check function	
Tyres: check tyre pressure (TPM)	
Diagnostic system: read out fault memory and transfer gear wear integrator; reset maintenance interval; read out soot mass in particle filter (Macan S Diesel only)	
Inside the vehicle	
Particle filter: replace filter element	
Outside the vehicle	
Check wiper blades	
All headlights: check adjustment	
Check and add reducing agent AdBlue® (Macan S Diesel only)	
Under the vehicle	
Drain engine oil, change oil filter (observe oil change service plan for the Macan/S Diesel)	
Tyres and spare wheel: check condition	
Brake lines: visual inspection for damage, routing and corrosion	
Brake hoses: visual inspection for damage	
Brake system: check brake pads and brake discs for wear (without removing wheels)	
Drive shafts: visual inspection of the boots for leaks and damage	
Cardan shaft: visual inspection of the rubber bellows for damage	
Radiators and air intakes: visual inspection for external contamination and blockage	
Engine compartment	
Fill in engine oil	
Coolant: check level and antifreeze	
Windscreen wiper/washer system: check fluid level; check window cleaner and antifreeze, depending on time of	
year, only use windscreen cleaners approved by Porsche	
* For country allocation, see overview of A, B and C markets	

PORSCHE

Intermediate maintenance (B markets*)

Macan

as of 2014 model

Vehicle Ident. No.	Work instruction for order no.		
Additional maintenance every 2 years (Labour operation: 03 51 00)			
Change brake fluid (use only original Porsche brake flu	uid)		
Prepare condition report for long-life guarantee			
Tyre sealing compound: check use-by date and replace if necessary			
□ Additional maintenance every 4 years			
(Labour operation: 03 52 00)			
	n vehicles with a mileage of less than 15,000 km/10,000		
miles in four years)			
Additional maintenance for spark plugs			
every 45000 km / 30000 mls or every 4 years	S		
(Labour operation: 03 81 00)			
Replace spark plugs			
Additional maintenance every 120000 km / 80000 mls or every 4 years			
(Labour operation: 03 85 00)			
Air cleaner: replace filter elements (Macan S/Turbo)			
Additional maintenance every 240000km / 160000mls or every 16 years			
(Labour operation: 03 95 00)			
All-wheel final drive: change oil			
Rear final drive: change oil			
□ Additional maintenance every 60000km / 40	000mls or every 4 years		
(Labour operation: 03 79 00)			
PDK transmission: change oil and filter			
□ Additional maintenance every 90000 km / 60	uuuu mis or every 4 years		
(Labour operation: 03 83 00) Air cleaner: replace filter element (Macan S Diesel)			
All cleaner. replace liner element (Macan's Dieser)			
Signature (mechanic):			
Test drive:			
Remote control, front seats, electric parking and foot b			
transmission, ParkAssist, cruise control, PSM switch, heating, sports exhaust system, air conditioning and instruments:			
check function			
Oils, fluids: visual inspection for leaks			

Signature (final check):

Porsche Centre